

COACT

GANGING BRACKET

INSTALLATION INSTRUCTIONS

1. Cut black material on bottom of units to expose the ganging bracket holes in the frames.
2. (Note: 1 ganging bracket can be used for ganging, but for a more secure attachment, 2 brackets are recommended.)
3. Align 2 pins on ganging brackets with 2 small holes in bottom of frame.
4. Thread knob screw #1 into threaded insert in center hole in frame until tight.
5. Thread knob screw #2 into unit to be ganged leaving knob screw loose.
6. Slide units tight together with thread of knob screw inside slot in ganging bracket.
7. Thread knob screw #2 until tight.

DIMENSIONS PROVIDED FOR APPROXIMATE LOCATION OF GANGING HOLES. LOCATION WILL VARY SLIGHTLY DUE TO UPHOLSTERY BUILD-UP.

